



# RECOIL

BLUETOOTH® EARBUDS W/ TRAVEL CASE



## ENGLISH

## MANUAL (ENGLISH)

### Charging the Bluetooth Earbuds

- Please make sure battery is fully charged. For best results (or to charge faster) do not use the earbuds while charging.
- To charge your Xtreme RECOIL Bluetooth Earbuds, connect the supplied cable to the Micro-USB charging port and connect the other end to a USB power outlet (5V adaptor not included). LED indicator will illuminate RED to indicate that the earbuds is charging. Allow approximately 3-4 hours charging time to fully charge the earbuds. When battery is fully charged, the LED indicator will turn off.

## Operating the Bluetooth Speaker

1. Turn the Recoil Earbuds on by holding the **☎** (2) Button for 2 seconds. There will be a startup sound and the LED indicator will begin flashing blue.
2. The earbuds will enter pairing mode. Enable Bluetooth search mode on your audio device and search for pairing name RECOIL and select it on your audio device. Once the earbuds have successfully connected, your audio device will state that the earbuds have been successfully connected.
3. Press the **☎** button (2) to answer calls, pause and play and hang up call.
4. To raise volume, long press the “+” (1) To change to the next track, short press the Volume “+” Button (1)
5. To lower volume, long press the “-” (3) To change to the previous track short press the Volume “-” Button (3)
6. To power down the earbuds, Hold the **☎** button (2) for 2 seconds, until the LED indicator will remain off.



## **ONE YEAR WARRANTY**

Xtreme warrants its products for ONE YEAR against defects in manufacturing under regular consumer use with original receipt of retail purchase.

We believe in our products and want to provide you with a replacement, if needed, but we have to know about the problem while the product is still under warranty. If you discover a defect covered by this warranty, please contact us about receiving a replacement. In order to use the products warranty the customer must provide proof of the retailers receipt.

*\*Any customers outside of the U.S. will be responsible for shipping and handling charges if a replacement is required that is not due to a manufacturing defect.*

**Xtreme's warranty is limited to our products only. Our warranty does not cover the replacement or repair cost of any third-party accessory, electronic device or personal property.**

For instructions about how to obtain warranty service for your product, please contact Customer Service at **[customerservice@xtremecables.com](mailto:customerservice@xtremecables.com)**

### **Package Contents:**

Recoil Earbuds

Micro USB Cable

3 Sized Ear Cushions (S/M/L)

Collar Clip

Travel Case

User Manual

## **Safety and Care Instructions:**

- Do not attempt to disassemble the unit.
- Repairs to electrical equipment should only be performed by a qualified service person. Improper repairs may place user at risk and void warranty.
- Do not puncture or harm the exterior surface of the product in any way.
- Do not drop or let the unit fall from high places, as doing so may damage the device.
- Do not use this unit for anything other than its intended user or purpose. Doing so may damage the device and void warranty.
- This product is not a toy. Keep out of reach of children.
- Do not expose batteries or battery pack to excessive heat or open flame.
- Do not expose the unit to extremely high or low temperatures as this will shorten the life of the device, destroy the battery, and /or distort certain parts.
- Do not use abrasive cleaning solvents to clean the unit.  
In order to prolong battery life, turn off when not in use.