




GHOST™

VERSATILE & LIGHTWEIGHT **BLUETOOTH®** EARBUDS



MANUAL (ENGLISH)

Charging Bluetooth Earbuds

- To charge your Xtreme Ghost Bluetooth earbuds, connect the supplied cable to the Micro-USB (5) charging port and connect the other end to a USB power outlet (5V adapter not included) for a minimum of 3 hours. LED is red when charging and turns off when fully charged.
- For best performance, please make sure battery is fully charged before use.

Operating Bluetooth Earbuds

1. Turn the Ghost Earbuds on by holding the Multifunction Button (3) until the LED lights (1) begin flashing blue and red.
2. The earbuds will enter pairing mode. Enable Bluetooth search mode on your audio device and search for pairing name "GHOST" and select it on your audio device. Once the Xtreme Ghost Bluetooth earbuds have successfully connected, your device will state that the device has been connected. The LED will flash blue.
3. Press the Multifunction Button (3) to answer calls, pause and play and hang up call.
4. To change to the next track, short press the " + " (4) To raise volume, long press the volume + Button (4)
5. To change to the previous track, short press the " - " (2) To lower volume, long press the Volume – Button (2)
6. To power down the earbuds, hold the Multifunction button (3) for 3 seconds until the device "chimes". The LED light indicator will remain off.

ONE YEAR WARRANTY

Xtreme warrants its products for ONE YEAR against defects in manufacturing under regular consumer use with original receipt of retail purchase.

We believe in our products and want to provide you with a replacement, if needed, but we have to know about the problem while the product is still under warranty. If you discover a defect covered by this warranty, please contact us about receiving a replacement. In order to use the products warranty the customer must provide proof of the retailers receipt.

**Any customers outside of the U.S. will be responsible for shipping and handling charges if a replacement is required that is not due to a manufacturing defect.*

Xtreme's warranty is limited to our products only. Our warranty does not cover the replacement or repair cost of any third-party accessory, electronic device or personal property.

For instructions about how to obtain warranty service for your product, please contact Customer Service at **customerservice@xtremecables.com**

Package Contents:

Bluetooth Earbuds

Micro USB cable

Manual

Safety and Care Instructions:

- Do not attempt to disassemble the unit.
- Repairs to electrical equipment should only be performed by a qualified service person. Improper repairs may place user at risk and void warranty.
- Do not puncture or harm the exterior surface of the product in any way.
- Do not drop or let the unit fall from high places, as doing so may damage the device.
- Do not use this unit for anything other than its intended user or purpose. Doing so may damage the device and void warranty.
- This product is not a toy. Keep out of reach of children.
- Do not expose batteries or battery pack to excessive heat or open flame.
- Do not expose the unit to extremely high or low temperatures as this will shorten the life of the device, destroy the battery, and /or distort certain parts.
- Do not use abrasive cleaning solvents to clean the unit.
In order to prolong battery life, turn off when not in use.