

AERO PRO

TRUE WIRELESS EARBUDS WITH CHARGING CASE



QUICK START GUIDE

GETTING STARTED

- ① Micro USB charging port
- ② Charging Case LED indicators
- 3 Charging Case Power Button

- 4 Left earbud LED indicator
- (5) Left control button
- (6) Right earbud LED indicator
- (Right control button



CHARGING YOUR CASE

- Charge on the go charging case, with the included micro USB cable for 2-3 hours. (LED (2A) will blink red) Do not charge longer than suggested time. Do not charge overnight.
- When LED (2A) is illuminated solid red battery case is fully charged.





CHARGING YOUR EARBUDS



- Place Right and Left Earbuds in battery case charging cradle and press the power button on the battery case (3)
- Charging case LED indicator (2B) will illuminate Blue and the earbud LED indicators (4, 6) will illuminate Red, indicating that the earbuds are charging properly. When Earbuds LEDs (4, 6) turn solid blue, earbud batteries are fully charged.
- After earbuds are fully charged, press the charging case power button (3) to turn the charging case OFF.

MONO MODE (SINGLE EARBUD USE)



- Remove earbud from charging cradle.
- Earbud will power on automatically. Led indicator begin flashing blue and red

STEREO MODE (DUAL EARBUD USE)



- Remove earbud from charging cradle.
- Earbuds will power on automatically. Led indicator on both earbuds will begin flashing blue indicating that the earbuds are linking together.
- Once Earbuds are linked together, one earbud's LED indicator will begin flashing blue and red indicating its ready to pair to your mobile device.

PAIRING



- Enable Bluetooth search mode on your mobile device and search for pairing name "AERO PRO" and select it on your mobile phone. Once the earbuds are successfully paired a notification will sound.
- Now you can enjoy your True Wireless Bluetooth Earbuds.

*Note: Once earbuds have been initially paired successfully with your mobile device they will automatically pair the next time they are powered on.

OPERATING BLUETOOTH EARBUDS

Function	Operation
Power On	Press (5) or (7) for 3 seconds
Power Off	Press (5) or (7) for 5 seconds
Play/Pause	Single press (5) or (7)
Answer/Reject	Answer (7) or Reject (5)
Earbuds	LED indications (4) & (6)
Power On	Red & Blue LED will flash alternately
Link Mode	Flashing Blue + Red
Paired Successfully	Flashing Blue
Low Battery	Flashing Red
Power Off	LED Off
Earbuds in Cradle	
Charging	Solid Red
Fully Charged	LED Off
01	C OLIA DOINO VOLID CACE
Charging Case	See CHARGING YOUR CASE