




AUDIO TRANSMITTER KIT

STREAM TV AUDIO TO **BLUETOOTH®** HEADPHONES OR SOUNDBARS



Package Contents:


1. Bluetooth® Audio Transmitter
2. Wall Mount
3. Micro USB Cable
4. 3.5mm Cable
5. 3.5mm to RCA Adapter

Manual

MANUAL (ENGLISH)

Operating the Bluetooth® Audio Transmitter

1. Using included Micro USB Cable and a USB wall charger (*not included*), fully charge your new Xtreme Home Theater Bluetooth® Audio Transmitter for a minimum of 3 hours. The LED charging indicator will illuminate red when charging. It will illuminate green when fully charged.
2. Connect the Transmitter to an audio source such as a TV or home stereo using the 3.5mm jack & included 3.5mm Aux Cable. (For audio devices with RCA output, the RCA to 3.5mm Adapter may be used).
3. Locate your Bluetooth® headphones or speaker that you would like to stream audio to. Be sure to power them on and activate pairing mode.
4. Turn on the Transmitter by switching the power switch (on the side) to the "ON" position. The Bluetooth LED indicator will illuminate solid blue.
5. Bluetooth® Transmitter begins searching for nearby Bluetooth® devices (Allow up to 20 sec for the Transmitter to pair).
6. Once the Transmitter and Bluetooth audio device are paired successfully the LED indicator will begin to flash blue slowly, indicating that the Transmitter is connected and ready to use.



FCC STATEMENT

This device complies with Part 15 of the FCC Rules. Operation is subject to following two conditions:

- (1) This device may not cause harmful interference, and
- (2) This device must accept any interference received, including interference that may cause undesired operation.

FCC RADIO FREQUENCY EXPOSURE STATEMENT

The device has been evaluated to meet general RF exposure requirements. The device can be used in fixed or mobile condition. The minimum separation distance is 20 cm.

NOTE

This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules, these limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses, and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications or television reception. However, there is no guarantee that interference will not occur in a particular installation. If this occurs, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- (1) Reorient or relocate the receiving antenna.
- (2) Increase the separation between the equipment and receiver.
- (3) Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- (4) Consult an experienced radio/TV technician for help or contact the customer service number below.

SAFETY AND CARE INSTRUCTIONS:

Please read and understand all instructions before using this product.

- Be sure to keep these instructions.
- Do not attempt to disassemble the unit. Repairs to electrical equipment should only be performed by a qualified service person. Improper repairs may place user at risk and void warranty.
- Do not expose this product to dripping or splashing of drinks or liquids of any kind.
- Avoid long exposure to direct sunlight, which may cause damage.
- Do not use the product in a strong magnetic field.
- Do not use this unit for anything other than its intended user or purpose. Doing so may damage the device and void warranty.
- Do not puncture or harm the exterior surface of the product in any way. This product is not a toy. Keep out of reach of children.
- Do not expose batteries or battery pack to excessive heat or open flame.
- Do not expose the unit to extremely high or low temperatures as this will shorten the life of the device, destroy the battery, and /or distort certain parts.
- Do not use abrasive cleaning solvents to clean the unit.
- In order to prolong battery life, turn off when not in use.

WARNING

Changes or modifications not expressly approved by the party responsible for compliance could void the user's warranty or authority to operate the equipment.

ONE YEAR WARRANTY

Xtreme warrants its products for ONE YEAR against defects in manufacturing under regular consumer use with original receipt of retail purchase.

We believe in our products and want to provide you with a replacement, if needed, but we have to know about the problem while the product is still under warranty. If you discover a defect covered by this warranty, please contact us about receiving a replacement. In order to use the products warranty the customer must provide proof of the retailers receipt.

**Any customers outside of the U.S. will be responsible for shipping and handling charges if a replacement is required that is not due to a manufacturing defect. If there is not a manufacturing defect, shipping and handling will be applied.*

Xtreme's warranty is limited to our products only. Our warranty does not cover the replacement or repair cost of any third-party accessory, electronic device or personal property.

For instructions about how to obtain warranty service for your product, please contact Customer Service at
customerservice@xtremecables.com