



# AURORA SPEAKER

BLUETOOTH® LIGHT SHOW SPEAKER



## ENGLISH

# MANUAL (ENGLISH)

## Aurora Speaker

### Charging Bluetooth® Speaker

- Please make sure battery is fully charged before initial use.
- To charge your Xtreme Aurora Bluetooth® Speaker, connect the supplied Micro USB cable into the Micro-USB charging port and connect the other end to a USB power outlet (5V adaptor not included). LED indicator will illuminate RED to indicate that the speaker is charging. Allow approximately 3-4 hours charging time to fully charge. When battery is fully charged, the LED will turn BLUE.

### Operating the Bluetooth® Speaker

1. Turn the Bluetooth® Speaker ON by switching the power switch to the ON position. The speaker will automatically enter pairing mode.
2. Enable Bluetooth® search mode on your smartphone and select pairing name "AURORA" on your Bluetooth® device list. The speaker will chime once your device is connected.
3. To raise and lower the volume level, adjust the volume level on your audio device. (Refer to your audio devices manual)
4. To go to Next/Previous track, select it on your audio device. (Refer to your audio devices manual)
5. To Power down the Speaker, switch the power switch to the "OFF" position. The LED lights will turn off. (Speaker will automatically pair with your device once its turned back on)

## **ONE YEAR WARRANTY**

Xtreme warrants its products for ONE YEAR against defects in manufacturing under regular consumer use with original receipt of retail purchase.

We believe in our products and want to provide you with a replacement, if needed, but we have to know about the problem while the product is still under warranty. If you discover a defect covered by this warranty, please contact us about receiving a replacement. In order to use the products warranty the customer must provide proof of the retailers receipt.

*\*Any customers outside of the U.S. will be responsible for shipping and handling charges if a replacement is required that is not due to a manufacturing defect.*

**Xtreme's warranty is limited to our products only. Our warranty does not cover the replacement or repair cost of any third-party accessory, electronic device or personal property.**

For instructions about how to obtain warranty service for your product, please contact Customer Service at **[customerservice@xtremecables.com](mailto:customerservice@xtremecables.com)**

### **Package Contents:**

Bluetooth® speaker x 1

Micro USB cable x 1

User manual x 1

## Important Safety Information

- Do not plug the unit in any outlet that does not have enough current to allow the device to function. The required specification of USB adapter is 5V1A. Refer to the specifications in this manual for power level of the unit.
  - Liquid: If this unit or its corresponding power adapter has liquid spilled on it, do not attempt to use the unit.
  - Do not attempt to use this product in an outdoor environment as elements such as rain, snow, hail, etc. can damage the product. In case of a storm, it is recommended that you unplug this device from the outlet.
  - Avoid placing this product next to objects that produce heat such as portable heaters, space heaters, or heating ducts.
- THERE ARE NO USER SERVICEABLE PARTS.** Do not attempt to open this product and expose the internal circuitry.