



INFINITY

BLUETOOTH® SPEAKER WITH 3D LIGHT SHOW



Package Contents:


Bluetooth® Speaker
Micro USB Charging Cable
Manual

CHARGING BLUETOOTH SPEAKER

Please make sure battery is fully charged before initial use. To charge your Xtreme Infinity Bluetooth® Speaker, connect the supplied Micro USB cable into the Micro USB charging port **(1)** and connect the other end to a USB power outlet (*5V adaptor not included*). The LED indicator **(2)** will illuminate RED to indicate that the speaker is charging. Allow approximately 3-4 hours charging time to fully charge the speaker. When battery is fully charged, the LED light will turn OFF.

OPERATING BLUETOOTH SPEAKER

1. Power the Infinity Speaker on by sliding the On/Off power switch **(3)** until the LED lights **(2)** begin flashing.
2. The speaker will enter pairing mode. Enable Bluetooth® search mode on your Bluetooth® enabled device and search for the pairing name "INFINITY" and select it on your audio device. Once the speaker is connected, the speaker will state that the device has been paired successfully.
3. Utilize your Bluetooth® enabled device to control playback functions as well as volume, on your Infinity Speaker.
8. Slide the Switch **(3)** to the OFF position to power down device.



FUNCTION KEY

1. Micro USB Port 2. LED Indicator 3. Power On/ Off

CARE AND MAINTENANCE

- Wipe the product with a damp cloth and dry thoroughly.
- Store the product in a dry area.
- Do not place the device on or near any hot surfaces.
- Please keep this manual in a safe place to be used for future reference.

IMPORTANT

- Do not use the product if it has been damaged in any way.
- Do not use the speaker for anything other than its intended use.
- Keep out of reach of children as this product is not a toy.

ONE YEAR WARRANTY

Xtreme warrants its products for ONE YEAR against defects in manufacturing under regular consumer use with original receipt of retail purchase.

We believe in our products and want to provide you with a replacement, if needed, but we have to know about the problem while the product is still under warranty. If you discover a defect covered by this warranty, please contact us about receiving a replacement. In order to use the products warranty the customer must provide proof of the retailers receipt.

**Any customers outside of the U.S. will be responsible for shipping and handling charges if a replacement is required that is not due to a manufacturing defect. If there is not a manufacturing defect, shipping and handling will be applied.*

Xtreme's warranty is limited to our products only. Our warranty does not cover the replacement or repair cost of any third-party accessory, electronic device or personal property.

For instructions about how to obtain warranty service for your product, please contact Customer Service at
customerservice@xtremecables.com

SPECIFICATIONS

Bluetooth® Version: 5.0

1200mAh Battery

3W Speaker

Wireless Range: 33ft

Charging Time: 3-4 Hours

Play Time: 2-3 Hours