



WIRELESS CHARGER CAR MOUNT

WITH AUTOMATIC OPEN & CLOSE



ENGLISH

855-999-8041 | www.XtremeCables.com

MANUAL (ENGLISH)

Wireless Charger Car Mount

1. Air vent installation:

Put the clip onto the air vent of your car. Insert the knob on back ball of the clip.

Insert and press the wireless mount onto the back ball of the air vent clip. Screw the knob clockwise to your preferred tightness.

2. Window or dashboard installation:

Place the dash/window mount on a flat surface, (or place on the included dash plate which can adhere to the dashboard) pull down the lever to secure.

Insert and press the wireless mount onto the back ball of the dash/window mount. Screw the knob clockwise to your preferred tightness.

3. Plug the USB-C cable to the wireless chargers input, then raise your phone in front of the wireless mount. The sensor will trigger the arms to open automatically you can then place your phone into the wireless mount. Do not let go until the arms have closed securely gripping your phone.

The LED light at the bottom of the wireless mount will light up red when not charging and blue when charging.

4. To remove phone from wireless mount press the release button on the bottom right side of the wireless mount and the mount will release your phone. Be sure to hold your phone as you press the release button as the arms open automatically.

In order to bring you the best experience, please read this user manual carefully and keep it on hand before use.

Overview



Wireless Mount



Knob



Air Vent Clip



USB-C Cable



Dash/Window Mount

ONE YEAR WARRANTY

Xtreme warrants its products for ONE YEAR against defects in manufacturing under regular consumer use with original receipt of retail purchase.

We believe in our products and want to provide you with a replacement, if needed, but we have to know about the problem while the product is still under warranty. If you discover a defect covered by this warranty, please contact us about receiving a replacement. In order to use the products warranty the customer must provide proof of the retailers receipt.

**Any customers outside of the U.S. will be responsible for shipping and handling charges if a replacement is required that is not due to a manufacturing defect. If there is not a manufacturing defect, shipping and handling will be applied.*

Xtreme's warranty is limited to our products only. Our warranty does not cover the replacement or repair cost of any third-party accessory, electronic device or personal property.

For instructions about how to obtain warranty service for your product, please contact Customer Service at **customerservice@xtremecables.com**

Package Contents:

Wireless Mount x 1

Knob x 1

Air Vent Clip x 1

Dash/Window Mount x 1

USB-C Cable x 1

User manual x 1

Important Safety Information

- Do not plug the unit in any outlet that does not have enough current to allow the device to function. The required specification of USB adapter is 5V1A. Refer to the specifications in this manual for power level of the unit.
- Liquid: If this unit or its corresponding power adapter has liquid spilled on it, do not attempt to use the unit.
- Do not attempt to use this product in an outdoor environment as elements such as rain, snow, hail, etc. can damage the product. In case of a storm, it is recommended that you unplug this device from the outlet.
- Avoid placing this product next to objects that produce heat such as portable heaters, space heaters, or heating ducts. THERE ARE NO USER SERVICEABLE PARTS. Do not attempt to open this product and expose the internal circuitry.