



ONYX™

BLUETOOTH® HEADPHONES W/ MIC



ENGLISH

MANUAL (ENGLISH)

1. Next Track Button/ Volume Up
2. Multifunction Button
(Power Button/Pause-Play/ Answer-Hang Up Calls)
3. Previous Track Button/ Volume Down
4. LED Indicator
5. 3.5mm Auxiliary Port
6. Micro USB Charging Port

Charging the Bluetooth Headphones

- To charge your Protégé Bluetooth headphones, connect a Micro USB cable (not included) to the Micro-USB (6) charging port and connect the other end to a USB power outlet (5V adaptor not included). The LED charging indicator will blink red, indicating that the headphones are charging properly. When the LED indicator switches to solid red, the headphones are fully charged. (To maximize the life of the battery, do not charge more than 3 hours.)
- For best sound performance, Please make sure battery is fully charged before use.

Operating the Bluetooth Speaker

1. Turn the headphones ON by holding the multi-function button ►|| (2) for 3 seconds. The LED light indicator (4) will begin flashing blue and red.
2. The headphones will enter pairing mode. Enable Bluetooth search mode on your audio device and search for pairing name "PROTÉGÉ" and select it on your audio device. Once the headphones have been successfully connected, the LED will flash blue.
3. Press the Multifunction ►|| Button (2) to answer calls, pause and play and hang up call.
4. To change to the next track, press ►| the button (1)
5. To change to the previous track, press the |◄ button (3)
6. To raise volume, press and hold the Volume " + " Button (1)
7. To lower volume, press and hold the Volume " - " Button (3)
8. To power down the headphones, hold the multi-function button ►|| (2) for 5 seconds. The LED light indicator will flash red 3 times and remain off.
9. To use headphones from a wired audio source, plug in the a 3.5mm audio cable into the "Aux" port (5) (Aux cable not included). The headphones will automatically switch from "Bluetooth" mode to "Auxiliary" mode. (Please note that the music controls on the headphones will not function while in Auxiliary mode)

ONE YEAR WARRANTY

Xtreme warrants its products for ONE YEAR against defects in manufacturing under regular consumer use with original receipt of retail purchase.

We believe in our products and want to provide you with a replacement, if needed, but we have to know about the problem while the product is still under warranty. If you discover a defect covered by this warranty, please contact us about receiving a replacement. In order to use the products warranty the customer must provide proof of the retailers receipt.

**Any customers outside of the U.S. will be responsible for shipping and handling charges if a replacement is required that is not due to a manufacturing defect.*

Xtreme's warranty is limited to our products only. Our warranty does not cover the replacement or repair cost of any third-party accessory, electronic device or personal property.

For instructions about how to obtain warranty service for your product, please contact Customer Service at **customerservice@xtremecables.com**

Safety and Care Instructions:

- Do not attempt to disassemble the unit.
 - Repairs to electrical equipment should only be performed by a qualified service person. Improper repairs may place user at risk and void warranty.
 - Do not puncture or harm the exterior surface of the product in any way.
 - Do not drop or let the unit fall from high places, as doing so may damage the device.
 - Do not use this unit for anything other than its intended user or purpose. Doing so may damage the device and void warranty.
 - This product is not a toy. Keep out of reach of children.
 - Do not expose batteries or battery pack to excessive heat or open flame.
 - Do not expose the unit to extremely high or low temperatures as this will shorten the life of the device, destroy the battery, and /or distort certain parts.
 - Do not use abrasive cleaning solvents to clean the unit.
- In order to prolong battery life, turn off when not in use.